



## ENGLISH

### KETTLE VT - 7023 Y

The kettle is intended for water boiling.

#### DESCRIPTION

1. Kettle body
2. Mesh filter
3. Lid
4. On/Off button «0/l»
5. Handle
6. Water level scale
7. Operation indicator
8. AC voltage selector 120 V / 220-240V
9. Cups

#### SAFETY MEASURES

Before using the unit, read this instruction manual carefully and keep it for future reference.

Use the unit for intended purposes only, as specified in this manual. Mishandling the unit can lead to its breakage and cause harm to the user or damage to his/her property.

• Open the lid (3) and fill the kettle with water. Close the lid (3).

• Insert the power plug into the mains socket.

• Switch the kettle on by setting the button (4) to the position «1», the operation indicator (7) will light up.

• Once water starts boiling, the kettle will be switched off automatically and the indicator (7) will go out. Pour water out and repeat the water boiling procedure 2-3 times.

• Wash the cups (9) in warm water with a neutral detergent.

**Note:**  
• When using the kettle, make sure that the lid (3) is closed tightly.

#### USAGE

• There is a two-position voltage selector on the bottom of the kettle. Before using the kettle make sure that unit operating voltage corresponds to the voltage of your mains.

• Open the lid (3) and fill the kettle with water up to the «MAX/0,5L» mark. Close the lid (3).

• Insert the power plug into the mains socket.

• Switch the kettle on by setting the button (4) to the position «1», the operation indicator (7) will light up.

• Once water starts boiling, the kettle will be switched off automatically and the indicator (7) will go out.

• After the kettle is switched off, wait for 10-20 seconds, then you can switch it on again for water boiling.

• To avoid the risk of fire, do not use adapters for connecting the kettle to the mains.

• If you accidentally switch the kettle on with insufficient amount of water, the automatic thermal switch will be on and the kettle will be switched off. In this case unplug the unit and let it cool down for 5-10 minutes, then fill the kettle with water and switch it on, the unit will operate in normal mode.

• Place the kettle on a flat stable surface; do not place the kettle on the edge of the table.

• Do not let the power cord hang from the edge of the table, make sure that the cord does not touch hot surfaces or sharp edges of furniture.

• Do not touch the power cord and power plug with wet hands.

• Do not switch the kettle on if it is empty.

• Use the kettle only for water boiling; do not heat or boil any other liquids.

• Make sure that the water level in the kettle is not below the minimal mark «0,2L/MIN» and not above the maximal mark «MAX/0,5L». If the water level exceeds the maximal mark, boiling water can splash outside of the kettle.

• Do not immerse the kettle into water or any other liquids.

• Do not wash the kettle and cups in a dishwashing machine.

• To avoid scalding by hot steam, do not bend over the kettle spout while it is operating.

• Do not use the kettle without the filter or if the lid is not closed tightly.

• Do not open the kettle lid while water boiling.

• Do not touch hot surfaces of the kettle, take it only by the handle.

• Be careful while carrying the kettle filled with boiling water.

• Unplug the unit before cleaning or when you are not using it.

• To avoid electric shock, do not immerse the unit into water or any other liquids.

• Do not wash the kettle and cups in a dishwashing machine.

• Do not allow children to touch the unit body and the power cord during the unit operation.

• This unit is not intended for usage by children under 8 years of age.

• This unit is not intended for usage by people (including children over 8) with physical, neural, mental deviations or with insufficient experience or knowledge. Such persons may use the unit only if they are under supervision of a person who is responsible for their safety and if they are given all the necessary and understandable instructions concerning the safe usage of the unit and information about danger that can be caused by its improper usage.

• Do not leave children unattended to prevent using the unit as a toy.

• For children safety reasons do not leave polyethylene bags, used as packaging, unattended.

**Attention!** Do not allow children to play with polyethylene bags or packaging film. **Danger of suffocation!**

• Never pull the power cord when disconnecting the unit from the mains, take the power plug and carefully remove it from the mains socket.

• Never use the unit if the power cord or the power plug is damaged, if the kettle works improperly or after the unit was dropped.

• Do not disassemble the unit by yourself, if any malfunction is detected or after the unit was dropped, apply to the nearest authorized service center.

• Keep the unit out of reach of children and disabled persons.

• Before taking the unit away for long storage, unplug it, pour out water and let the unit cool down.

• To avoid condensation during long storage, wipe the kettle dry.

• Keep the kettle away from children in a dry cool place.

#### Delivery set

1. Kettle – 1 pc.

2. Cups – 2 pc.

3. Instruction manual – 1 pc.

#### Technical specifications

Power supply: 120/220-240 V ~ 50/60 Hz

Maximal power: 550-650 W

Maximal water capacity: 0,5 L

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

The manufacturer reserves the right to change the specifications of the unit without a preliminary notification.

#### THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

#### BEFORE THE FIRST USE

After unit transportation or storage at low temperature, it is necessary to keep it for at least two hours at room temperature.

• Unpack the unit and remove all packaging materials that can prevent unit operation.

• Make sure that the voltage selector (8) is set to the position that corresponds to the mains voltage.

This product conforms to the EMC-Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (20

